

### Replacement Pull String

#### Description

The FieldShield Replacement Pull String allows the installer to replace string in microduct or blow string into unoccupied duct.



#### Pre-Configured Part Numbers

Part Number	Description
FS-PUL-STRING-2000F	Replacement Pull String, 50 lb., 2000 Foot Spool
FS-PUL-YOURX	Pulling Tool, YOURx Breakout, for 50 lb. Maximum Pulling Force, 10mm FlexPort

### Airtight Coupler

#### Description

Airtight Couplers are designed to provide simple, 2-click plug-and-play joining of microducts, enabling longer runs and safe pushing and pulling performance.



#### Pre-Configured Part Numbers

Part Number	Description
FS-CPLR-7MM-7MM-10	FieldShield Microduct Airtight Coupler, 7 mm to 7 mm, 10 pack
FS-CPLR-8MM-8MM-10	FieldShield Microduct Airtight Coupler, 8 mm to 8 mm, 10 pack
FS-CPLR-10MM-10MM-10	FieldShield Microduct Airtight Coupler, 10 mm to 10 mm, 10 pack
FS-CPLR-12.7MM-12.7MM-10	FieldShield Microduct Airtight Coupler, 12.7 mm to 12.7 mm, 10 pack
FS-CPLR-14MM-14MM-10	FieldShield Microduct Airtight Coupler, 14 mm to 14 mm, 10 pack

### Airtight Transition Coupler

#### Description

Airtight Transition Couplers are used to join two different sizes of microduct.



#### Pre-Configured Part Numbers

Part Number	Description
FS-CPLR-8MM-10MM-10	FieldShield Microduct Airtight Transition Coupler, 8 mm to 10 mm, 10 pack
FS-CPLR-10MM-12.7MM-10	FieldShield Microduct Airtight Transition Coupler, 10 mm to 12.7 mm, 10 pack
FS-CPLR-12.7MM-14MM-10	FieldShield Microduct Airtight Transition Coupler, 12.7 mm to 14 mm, 10 pack